Cylindrical Type Photoelectric Sensor

Features

[Common]

- Excellent noise immunity and minimal influence from ambient light
 Power/Qutput reverse polarity protection circuit
- Power/Output reverse polarity protection circuit, output short over current protection circuit
- Mutual interference prevention function (except through-beam type)
 Sensitivity adjuster
- Sensitivity adjuster
- Light ON, Dark ON switchable by control wire

[BRQT, BRQM, BRQP Series (front sensing type)]

- Various materials: Plastic, Metal (Ni-plated Brass), Stainless steel 316L
- Long sensing distance: 30m (through-beam type)
- Body size BRQT, BRQM: Standard
 BRQD: Standard
 Chart h
- BRQP: Standard, Short body
- Protection structure BRQT: IP67 (IEC standard), IP69K (DIN standard) BRQM, BRQP: IP67 (IEC standard)

[BRQPS Series (side sensing type)]

Protection structure: IP67 (IEC standard)

Please read "Safety Considerations" in the instruction manual before using.



[BRQT, BRQM, BRQP Series (front sensing type)]

BRQM-A

BRQP-B

Plastic Short-body

Ni-plate Brass Standard







BRQP-A Plastic Standard



Reflector (MS-2A)



[BRQPS Series (side sensing type)]





Reflective tape (MST series)

Ordering Information

%The model name with '-C' is connector type.%Reflective tape (MST series) is sold separately.

Reflector

(MS-2S)

RQ	Т		5		Μ	-	Т		ן כ	Т	- ji	÷	A	۱ -	- (C	-	P				
	Τ								Γ			Ξ.			-	Г	-	С	ontrol		Front sensing type	Side sensing type
																		0	utput	No mark	NPN open collector	output
																				Р	PNP open collector	output
																Co	onne	ectio	n	No mark	Cable type	
																				С	Connector type	
														App	bear	ranc	e			A	Standard	Standard
													ı							В	Short body ^{×1}	—
												E	mit	ter/F	Rece	eive	r			1	Emitter	
											<u> </u>									2	Receiver	
											Out	put								-T	Transistor output	
									Po	owe	r su	ippl	y							D	DC power	
								Son	ein	a tv	no									Т	Through-beam type	
							_	Sen	SIII	y iy	he									- P	Retroreflective type	built-in polarizing filter
															D	Diffuse reflective typ	e					
					S	Sens	ing	dist	anc	e u	nit									No mark	mm	
				Ser	nsing distance													М	m			
			L													Number	Sensing distance					
			Forn	n of	ser	nsing	g													No mark	Front sensing type	-
		Case material							S	—	Side sensing type											
	c									Т	Stainless steel 316L	_										
																				М	Brass, Ni-plate	-
Itom																				P	Plastic	Plastic
nem																				BRQ	Cylindrical type phot	oelectric sensor

%1: This is only for BRQP Series.

Ximi This information is intended for product management of through-beam type. (no need to refer when selecting model)



SENSORS

Cylindrical Type Photoelectric Sensor (front sensing type) Specifications

	-		1		1	1	1			-					
le	NPN o	open tor output	BRQ□5M- TDT□-□	BRQ□20M- TDT□-□	BRQ⊡30M- TDT⊡-⊡	BRQ⊡3M- PDT⊡-⊡	BRQ⊡100- DDT⊡-⊡	BRQ⊡400- DDT⊡-⊡	BRQD1M- DDTD-D						
Mod	PNP o collect	pen tor output	BRQ⊡5M- TDT⊡-⊡-P	BRQ_20M- TDTP	BRQ_30M- TDTP	BRQ⊡3M- PDT⊡-⊡-P	BRQ_100- DDTP	BRQ_400- DDTP	BRQ_1M- DDTP	CONTROLLERS					
Sen	Sensing type		Through-beam	ı type		Retroreflective type (built-in polarizing filter)	MOTION DEVICES								
Sen	Sensing distance		5m	20m	30m	3m ^{*1}	100mm ^{*2}	400mm ^{*2}	1m ^{**3}]					
Sen	Sensing target		Opaque mater	ials of min. Ø7mm	ı	Opaque materials of min. Ø75mm	Opaque, trans	SOFTWARE							
Hyst	teresis		<u> </u>				Max. 20% at ra	ated sensing dist	tance]					
Res	ponse t	ime	Max. 1ms												
Pow	er supp	oly	10-30VDC ±10% (ripple P-P: max.10%)												
Curr	ent con	nsumption	Emitter/Receiver: max. 20mA Max. 30mA												
Ligh	t source	е	Red LED (660nm) Infrared LED (660nm) Red LED (660nm)												
Sens	sitivity a	idjustment	Sensitivity adju	uster]					
Ope	ration n	node	Selectable Lig	ht ON or Dark ON	by control wire (v	vhite)				(A) Dhotooleatria					
Con	Control output		NPN or PNP open collector output · Load voltage: max. 30VDC · Load current: max. 100mA · Residual voltage: max. 2VDC												
Prot	Protection circuit		Power/Output reverse polarity protection circuit, output short over current protection circuit, interference prevention function (except through-beam type)												
Indio	Indicator		Operation indicator: yellow LED, stability indicator: green LED (emitter power indicator of through-beam type: red LED)												
Connection		Cable type, connector type													
Insu	Insulation resistance		Over 20MΩ (at 500VDC megger)												
Nois	Noise immunity		±240V the square wave noise (pulse width:1μs) by the noise simulator												
Diel	Dielectric strength		1,000VAC 50/60Hz for 1 minute												
Vibr	Vibration		1.5mm amplitude at frequency of 10 to 55Hz in each X, Y, Z direction for 2 hours												
Sho	Shock		500m/s ² (approx. 50G) in X, Y, Z direction for 3 times												
6 t	승는 Ambient illu.		Sunlight: max. 11,000lx, Incandescent lamp: max. 3,0001x (receiver illumination)												
1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	Ambie	ent temp.	-25 to 60°C, storage: -30 to 70°C												
шс	Ambie	ent humi.	35 to 85%RH, storage: 35 to 85%RH												
Prot	ection s	structure	· BRQ1 Series: IP67 (IEC standard), IP69K (DIN standard) · BRQM, BRQP Series: IP67 (IEC standard)												
Mate	Material		Case: BRQT Series - stainless steel 316L / BRQM Series - brass, Ni-plate / BRQP Series - polycarbonate Lens, Lens cover: polymethyl methacrylate acrylic												
Cab	Cable ^{*4} Cable type		Ø4mm, 4-wire, 2m (emitter of through-beam type: Ø4mm, 2-wire, 2m) (AWG26, core diameter: 0.52mm, number of cores: 20, insulator out diameter: Ø1mm)												
1	Individ		Al Reflector (MS-2A)												
ACCE	Common		M18 fixing nut: 4, adjustment screwdriver M18 fixing nut: 2, adjustment screwdriver												
App	Approval		CEcNUs			• •	•			(H) Rotary					
			BRQT-A/BRQM-A; approx. 220g (approx. 140g) BRQT-A/BRQM-A; approx. 150g (approx. 70g)												
*5	Cable type		BRQP-A: approx. 160g (approx. 110g) BRQP-A: approx. 120g (approx. 60g)							(I)					
ght			BRQP-B: approx. 150g (approx. 100g) BRQP-B: approx. 120g (approx. 50g)							Connectors/ Connector Cables/					
Wei	Single Connector type		BRQT-A/BRQI BRQP-A: appr	M-A: approx. 160g ox. 110g (approx.	BRQT-A/BRQM BRQP-A: appro	λI-A/BRQM-A: approx. 140g (approx. 30g) λP-A: approx. 110g (approx. 15g)									
1	E	BRQP-B: approx. 100g (approx. 20g) BRQP-B: approx. 100g (approx. 10g)													

X1: The sensing distance is specified with using the MS-2A reflector. The distance between the sensor and the reflector should be set over 0.1m. When using reflective tapes, the reflectivity will vary by the size of the tape. Please refer to the I Reflectivity by Reflective Tape Model' table before using the tape.

%2: Non-glossy white paper 100×100mm.

X3: Non-glossy white paper 300×300mm.

%4: M12 connector cable is sold separately.

%5: The weight includes packaging. The weight in parenthesis is for unit only.

*The temperature or humidity mentioned in Environment indicates a non freezing or condensation.

Dimensions

(unit: mm)



• BRQT_-TDTA(-P)





Power indicator (red) Power indicator 69 (red) 59 38.5 Operation indicator (yellow) 2.5 31 M12×1 œ 10. Sensitivity Stability indicator M18×1 adjuster (green)

• BRQT -TDTA-C(-P)

• BRQP_-TDTA(-P)





• BRQP_-TDTB(-P)





BRQ Series

• M18 fixing nut



Sold separatelyBracket(BK-BR-A)



• Reflector

·MS-2A



• Fixing cap (BK-BR-B, only for BRQP_-___B-_)



• Connection cable

· CIDH4-



· CLDH4-



diameter: Ø1.65mm)

Specification of connector cable: Ø6mm, 4-wire, 2m/3m/5m/7m (AWG22, core diameter: 0.08mm, number of cores: 60, insulator out)

Reflective tape



	(unit: mm)
Model	A
MST-50-10	□50
MST-100-5	□100
MST-200-2	200

(unit: mm)

Autonics





\odot Diffuse reflective type



Control Output Circuit Diagram

• Through-beam/Retroreflective/Diffuse reflective type



*Before using this unit, select Light ON/Dark ON with control cable.

(Light ON: connect control cable with 0V/Dark ON: connect control cable with +V)

%If short-circuit the control output terminal or supply current over the rated specification, normal control signal is not output due to the output short over current protection circuit.

Connections for Connector Part



	Oshla	Application						
Pin No.	Cable	Diffuse/	Through-beam type					
	00101	Retroreflective type	Emitter	Receiver				
1	Brown	30VDC	30VDC	30VDC				
2	White	CONTROL	N.C	CONTROL				
3	Blue	GND	GND	GND				
4	Black	OUTPUT	N.C	OUTPUT				

• Connector cable (sold separately) %Please refer to the connector cable part.

M12 Connector pin

Operation Timing Diagram

◎ Through-beam type



© Retroreflective/Diffuse reflective type



%The waveforms of 'Operation indicator' and 'Transistor output' are for Light ON operation. They are opposite operation for Dark ON operation.



(A) Photoelectric Sensors

(B) Fiber Optic Sensors

(C) LIDAR

(D) Door/Area Sensors

(E) Vision Sensors

(F)

Proximity Sensors

(G) Pressure Sensors

(H) Rotary Encoders

(I) Connectors/ Connector Cables/ Sensor Distribution Boxes/ Sockets

Connections

• Through-beam type





<Connector type>



• Retroreflective type

<Cable type>



• Diffuse reflective type





<Connector type>





Installation and Adjustment

Install the sensor to the desired place and check the connections. Supply the power to the sensor and adjust the optical axis and the sensitivity as following.

When using the reflective type photoelectric sensors closely over three units, it may result in malfunction due to mutual interference.

When using the through-beam type photoelectric sensors closely over two units, it may result in malfunction due to mutual interference.

When installing the product, tighten the screw with a tightening torque of 14.7N·m for BRQT/BRQM and 0.39N·m for BRQP.

O Through-beam type

- 1. Supply the power to the photoelectric sensor, after setting the emitter and the receiver facing each other.
- Set the receiver in center of position in the middle of the operation range of indicator adjusting the receiver or the emitter right and left, up and down.
- 3. After adjustment, check the stability of operation putting the object at the optical axis.
- %If the sensing target is translucent body or smaller than Ø7mm, it can be missed by sensor cause light penetrate it.



○ Retroreflective type

- Supply the power to the photoelectric sensor, after setting the photoelectric sensor and the reflector (MS-2A) or reflective tape in face to face.
- 2. Set the photoelectric sensor in the position which indicator turns on, as adjusting the reflector or the sensor right and left, up and down.
- 3. Fix both units tightly after checking that the unit detects the target.
- XSensitivity adjustment
 - : Refer to the diffuse reflective type's.



O Diffuse reflective type

1. The sensitivity should be adjusted depending on a sensing target or mounting place.



- Set the target at a position to be detected by the beam, then turn the sensitivity adjuster until position

 where the operation indicator turns ON from min. position of the Sensitivity adjuster.
- 3. Take the target out of the sensing area, then turn the Sensitivity adjuster until position (b) where the the operation indicator turns ON. If the indicator dose not turn ON, max. position is (b).
- 4. Set the sensitivity adjuster at the center of two switching position (a), (b).
- *Be aware of the fact that sensing distance can be different by size, surface and gloss of the target.



Reflectivity by Reflective Tape Model

Model	Standard	Short body
MST-50-10 (50×50mm)	40%	40%
MST-100-5 (100×100mm)	50%	80%
MST-200-2 (200×200mm)	80%	85%

%This reflectivity is based on the reflector (MS-2A).

※Reflectivity may vary depending on usage environment and installation conditions.

The sensing distance and minimum sensing target size increase as the size of the tape increases. Please check the reflectivity before using reflective

tapes.

%For using reflective tape, installation distance should be min. 20mm. Sensors (C) LiDAR

Fiber Optic

SENSORS

CONTROLLERS

MOTION DEVICES

SOFTWARE

(D) Door/Area Sensors

(E) Vision Sensors

(F) Proximity

Sensors

(G) Pressure

Sensors

(H) Rotary Encoders

(1)

Connectors/ Connector Cables/ Sensor Distributior Boxes/ Sockets